

Термотрансферная бумага для цветных лазерных принтеров.  
Позволяет переносить изображение на светлый текстиль с помощью термопресса.

## Руководство для печати и переноса изображения на светлый хлопок

### Установки лазерного принтера

Изображение: **зеркальное**  
Режим печати: см. на 2-й странице  
Источник бумаги: **лоток ручной подачи**

### Установки термопресса

Температура: **200°C**  
Давление **среднее** или **максимальное**  
Время печати: **10-15 секунд**

### Подготовка текстиля

Переносите изображение на предварительно нагретый текстиль.  
Перед нанесением изображения расположите футболку на рабочей поверхности термопресса и закройте пресс на несколько секунд.

### Процесс переноса изображения

1. Положите бумагу Classic+ Universal изображением на ткань.
2. Сверху положите один лист силиконовой бумаги.
3. Закройте пресс на 10-15 секунд.
4. Откройте пресс, удалите силиконовую бумагу, аккуратно снимите бумагу Classic+ Universal с ткани.
5. Положите один лист силиконовой бумаги глянцевой стороной на отпечатанное изображение и закройте пресс на 10 секунд.
6. Откройте пресс и снимите силиконовую бумагу.

### Стирка

Бережная стирка при температуре до 40°C.  
Рекомендуется естественная сушка. После стирки изображение прогладить утюгом через пергамент, кальку или силиконовую бумагу.



## PRINTER COMPATIBILITY LIST Classic + Universal

BRAND	MODEL	PRINTER SETTINGS
<b>CANON</b>	all CLC	HEAVY PAPER
	CP 660	UNSUITABLE
	IRC 2880	HEAVY PAPER
	C1	HEAVY PAPER 2
<b>DEVELOP</b>	QC 2235+	LABEL 1
	QC 3101	LABEL 1
	ineo 450+	LABEL 1
	ineo 250+	LABEL
<b>EPSON</b>	Laser C 8500	UNSUITABLE
	Laser C 8600	LABEL
	Aculaser C 1100	UNSUITABLE
	Aculaser C1900S	LABEL
<b>HP</b>	1500L	HEAVY PAPER
	2500 L	HEAVY PAPER
	2550 L	TOUGH PAPER
	3500 N	LABEL
	4550	HEAVY PAPER
	3550	LABEL
	3600	LABEL
<b>KYOCERA</b>	FS-C5020N	SPECIAL/HEAVY PAPER
	KM-C2520	HEAVY PAPER
	KM-C2525E	HEAVY PAPER
	KM-C3225	HEAVY PAPER
	KM-C3232E	HEAVY PAPER
<b>LEXMARK</b>	KM-C4035E	HEAVY PAPER
	C912	HEAVY PAPER
<b>MINOLTA</b>	MagiColor 2	TRANSPARENCY FOIL
	Bizhub C250/252	LABEL 1
	Bizhub C350/351	LABEL 1
	Bizhub C450/451	LABEL 1
	Bizhub Pro C500	NORMAL 105g
	CF 2002	LABEL 1
	CF 3102	LABEL 1 or 2
	QMS 2200	LABEL
	QMS 2300 DL	THICK STOCK
	QMS 2350	THICK STOCK
	MC 2400 W	LABEL
	QMS 6100 DL	HEAVY PAPER
	Bizhub C253	LABEL 1
	Bizhub C203	LABEL 1
	Bizhub C353	LABEL 1
<b>SHARP</b>	MX2300N	HEAVY PAPER

BRAND	MODEL	PRINTER SETTINGS	
<b>NASHUATEC</b>	DSC 328	HEAVY PAPER	
	MPC2000	THICK PAPER	
	MPC2500AD	THICK PAPER	
	MPC2500e	THICK PAPER	
	SPC 420DN	THICK 1	
	<b>OKI</b>	C 3100/3200	LABEL
		C3300-3400	GLOSSY
		C 5200/5500	LABEL
		C5600-5900	LABEL 2
		8600-8800	LABEL 2
C 5200/5400		LABEL	
C 5700		GLOSSY	
C 9300/9500		LABEL	
C 9600		LABEL	
C 9800		LABEL	
<b>RICOH</b>		Aficio AP3800C	LABEL
		Aficio 2228C	HEAVY PAPER
	Aficio C 811	THICK PAPER 3	
	Aficio CS510E	THICK PAPER 3	
	Aficio DSC428	THICK PAPER	
<b>TALLY</b>	AficioCL4000DN	THICK 1	
	8004/81004	LABEL	
	8008	LABEL	
	8204	LABEL	
	8006e	HEAVY PAPER	
<b>TOSHIBA</b>	eStudio 211c	THICK 2	
	eStudio 311c	THICK 2	
	eStudio2500c	THICK 2	
	eStudio3500c	THICK 2	
	eStudio3510c	THICK 2	
<b>UTAX</b>	CDC1526D	HEAVY PAPER	
<b>XANTE</b>	600	HEAVY PAPER	
	1200 PRO	HEAVY PAPER	
	ILUMINA	LABEL	
<b>XEROX</b>	DC 12	HEAVY PAPER	
	DC 3535	NORMAL PAPER	
	Workcenter 3545	LABEL	
	DC 50	HEAVY PAPER	
	M 24	THIN PAPER	
	Phaser 7400	THIN PAPER	
	Phaser 7750	NORMAL PAPER	
	DC 240/250	HEAVY PAPER 1	
DC 1250	THICK PAPER		



## ▶▶▶ HEAT TRANSFER INSTRUCTIONS

### Instructions for Printing onto **Light Colored Textiles** with **Classic + Universal**

#### ▶▶▶ PRINT SETTINGS

##### COLOR COPIER

**Paper Mode:** See list on reverse side

**Image Mode:** Mirror image

**Feeding:** Bypass (manual feeding)

##### LASER PRINTER

**Paper Mode:** See list on reverse side

**Image Mode:** Mirror image

**Feeding:** Bypass (manual feeding)

#### ▶▶▶ TRANSFER SETTINGS

	<b>AUTOMATIC HEAT PRESS</b>	<b>MANUAL HEAT PRESS</b>
<b>PRESSURE</b>	5 bar (70 PSI)	High/maximum
<b>TEMPERATURE</b>	200°C (390°F)	200°C (390°F)
<b>TIME</b>	10-15 seconds	10-15 seconds
<b>FIXING</b>	10 seconds	10 seconds

#### ▶▶▶ TRANSFER APPLICATION

- ▶ Place the textile on the lower plate.
- ▶ Place **FOREVER Classic + Universal** onto the t-shirt.
- ▶ Press for 10-15 seconds.
- ▶ Remove the transfer paper immediately.  
(Do not in any event take the t-shirt off the press before the transfer paper has been peeled off.)
- ▶ To improve the washability cover the print with the silicone paper **Glossy Finish** (Antistick) and press again for 10 seconds.
- ▶ For a softer touch stretch the garment into the width.

#### ▶▶▶ WASHING

- ▶ **Up to 40° C** (cold wash cycle).

#### ▶▶▶ IRONING

- ▶ **When ironing cover the print with baking paper.**