

Термотрансферная бумага для цветных лазерных принтеров.
Позволяет переносить изображение на светлый текстиль с помощью термопресса.

Руководство для печати и переноса изображения на светлый хлопок

Установки лазерного принтера

Изображение: **зеркальное**
Режим печати: см. на 2-й странице
Источник бумаги: **лоток ручной подачи**

Установки термопресса

Температура: **200°C**
Давление **среднее** или **максимальное**
Время печати: **10-15 секунд**

Подготовка текстиля

Переносите изображение на предварительно нагретый текстиль.
Перед нанесением изображения расположите футболку на рабочей поверхности термопресса и закройте пресс на несколько секунд.

Процесс переноса изображения

1. Положите бумагу Classic+ Universal изображением на ткань.
2. Сверху положите один лист силиконовой бумаги.
3. Закройте пресс на 10-15 секунд.
4. Откройте пресс, удалите силиконовую бумагу, аккуратно снимите бумагу Classic+ Universal с ткани.
5. Положите один лист силиконовой бумаги глянцевой стороной на отпечатанное изображение и закройте пресс на 10 секунд.
6. Откройте пресс и снимите силиконовую бумагу.

Стирка

Бережная стирка при температуре до 40°C.
Рекомендуется естественная сушка. После стирки изображение прогладить утюгом через пергамент, кальку или силиконовую бумагу.



PRINTER COMPATIBILITY LIST FOREVER Classic + Universal

BRAND	MODEL	PRINTER SETTINGS
CANON	all CLC	HEAVY PAPER
	CP 660	UNSUITABLE
	IRC 2880	HEAVY PAPER
	C1	HEAVY PAPER 2
DEVELOP	QC 2235+	LABEL 1
	QC 3101	LABEL 1
	ineo 450+	LABEL 1
	ineo 250+	LABEL
EPSON	Laser C 8500	UNSUITABLE
	Laser C 8600	LABEL
	Aculaser C 1100	UNSUITABLE
	Aculaser C1900S	LABEL
HP	1500L	HEAVY PAPER
	2500 L	HEAVY PAPER
	2550 L	TOUGH PAPER
	3500 N	LABEL
	4550	HEAVY PAPER
	3550	LABEL
	3600	LABEL
	KYOCERA	FS-C5020N
	KM-C2520	HEAVY PAPER
	KM-C2525E	HEAVY PAPER
	KM-C3225	HEAVY PAPER
	KM-C3232E	HEAVY PAPER
	KM-C4035E	HEAVY PAPER
LEXMARK	C912	HEAVY PAPER
MINOLTA	MagiColor 2	TRANSPARENCY FOIL
	Bizhub C250/252	LABEL 1
	Bizhub C350/351	LABEL 1
	Bizhub C450/451	LABEL 1
	Bizhub Pro C500	NORMAL 105g
	CF 2002	LABEL 1
	CF 3102	LABEL 1 or 2
	QMS 2200	LABEL
	QMS 2300 DL	THICK STOCK
	QMS 2350	THICK STOCK
	MC 2400 W	LABEL
	QMS 6100 DL	HEAVY PAPER
	Bizhub C253	LABEL 1
	Bizhub C203	LABEL 1
	Bizhub C353	LABEL 1
SHARP	MX2300N	HEAVY PAPER

BRAND	MODEL	PRINTER SETTINGS	
NASHUATEC	DSC 328	HEAVY PAPER	
	MPC2000	THICK PAPER	
	MPC2500AD	THICK PAPER	
	MPC2500e	THICK PAPER	
	SPC 420DN	THICK 1	
	OKI	C 3100/3200	LABEL
		C3300-3400	GLOSSY
		C 5200/5500	LABEL
		C5600-5900	LABEL 2
		8600-8800	LABEL 2
	C 5200/5400	LABEL	
	C 5700	GLOSSY	
	C 9300/9500	LABEL	
	C 9600	LABEL	
	C 9800	LABEL	
RICOH	Aficio AP3800C	LABEL	
	Aficio 2228C	HEAVY PAPER	
	Aficio C 811	THICK PAPER 3	
	Aficio CS510E	THICK PAPER 3	
	Aficio DSC428	THICK PAPER	
	AficioCL4000DN	THICK 1	
TALLY	8004/81004	LABEL	
	8008	LABEL	
	8204	LABEL	
	8006e	HEAVY PAPER	
TOSHIBA	eStudio 211c	THICK 2	
	eStudio 311c	THICK 2	
	eStudio2500c	THICK 2	
	eStudio3500c	THICK 2	
	eStudio3510c	THICK 2	
UTAX	CDC1526D	HEAVY PAPER	
XANTE	600	HEAVY PAPER	
	1200 PRO	HEAVY PAPER	
	ILUMINA	LABEL	
XEROX	DC 12	HEAVY PAPER	
	DC 3535	NORMAL PAPER	
	Workcenter 3545	LABEL	
	DC 50	HEAVY PAPER	
	M 24	THIN PAPER	
	Phaser 7400	THIN PAPER	
	Phaser 7750	NORMAL PAPER	
	DC 240/250	HEAVY PAPER 1	
DC 1250	THICK PAPER		



▶▶▶ HEAT TRANSFER INSTRUCTIONS

Instructions for Printing onto **Light Colored Textiles** with **FOREVER Classic + Universal**

▶▶▶ PRINT SETTINGS

COLOR COPIER

Paper Mode: See list on reverse side

Image Mode: Mirror image

Feeding: Bypass (manual feeding)

LASER PRINTER

Paper Mode: See list on reverse side

Image Mode: Mirror image

Feeding: Bypass (manual feeding)

▶▶▶ TRANSFER SETTINGS

	AUTOMATIC HEAT PRESS	MANUAL HEAT PRESS
PRESSURE	5 bar (70 PSI)	High/maximum
TEMPERATURE	200°C (390°F)	200°C (390°F)
TIME	10-15 seconds	10-15 seconds
FIXING	10 seconds	10 seconds

▶▶▶ TRANSFER APPLICATION

- ▶ Place the textile on the lower plate.
- ▶ Place **FOREVER Classic + Universal** onto the t-shirt.
- ▶ Press for 10-15 seconds.
- ▶ Remove the transfer paper immediately.
(Do not in any event take the t-shirt off the press before the transfer paper has been peeled off.)
- ▶ To improve the washability cover the print with the silicone paper **Glossy Finish** (Antistick) and press again for 10 seconds.
- ▶ For a softer touch stretch the garment into the width.

▶▶▶ WASHING

- ▶ **Up to 40° C** (cold wash cycle).

▶▶▶ IRONING

- ▶ **When ironing cover the print with baking paper.**